



Subject to change without prior notice!

Document number: 65300 Rev.1.1

Eskilstuna 2017-09-19 DF

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	44368 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT802 Gauge PHS70/80-2400	50777
5	1	TX104 Gauge PHS100/150-2400	38831500
5	1	AMT151 Gauge, Ø100 mm PHS150-2400L	45036
6	1	AAM18 Gauge adapter (Not needed for PHS150-2400L)	44380
7	1	O-ring	[A D]
8	1	Spring	[A D]
9	1	Ball	[A D]
11	1	Ball	[A D]
13	1	Ball	[A D]
14	2	Plug	[A D]
15	2	Packing	[A D]
16	1	Washer	[A D F]
17	1	Piston	[D F]
18	1	O-ring	[A D F]
19	1	Supportring	[A D F]
20	1	Wiper	[A D]
21	1	O-ring	[A D]
22	1	Piston	[D F]
23	1	Housing	45051 [D]
24	1	O-ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1	Ball	[A D]
35	1	Plug	[A D]
36	1	Safety valve PHS70	44388
36	1	Safety valve PHS80	44389
36	1	Safety valve PHS100	44390
36	1	Safety valve PHS150	44391
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-ring	[A D]
40	1	End plate, front	[E]
41	1	O-ring	[A E]
42	1	Ball	[A E]
43	1	Screw	[E]

Pos.	QTY	Description	Part No.
44	1	Oil container	[E]
45	1	Plug	[A E]
46	1	Packing	[A E]
47	1	O-ring	[A E]
48	1	End plate, rear	[E]
49	1	Yoke	44370
50	1	Packing	[A E]
51	1	Nut	[A E]
52	1	Label, read manual	[A E]
53	1	Label, release function	[A E]
54	2	Label, REHOBOT	[A E]
		Repair kit	45050
		Handle assembly PHS70/80/100/150-2400	45058
		Handle assembly PHS150-2400L	45592
		Release valve assembly	45054
		Pump unit Cpl. PHS70- , PHS80-	45060
		Pump unit Cpl. PHS100- , PHS150-	45055
		Tank assembly -2400	45063
		Piston kit PHS70-, PHS80-	45062
		Piston kit PHS100-, PHS150-	45057

- [A] Included in Repair kit
- [B] Included in Handle assembly
- [C] Included in release valve assembly
- [D] Included in Pump unit Cpl.
- [E] Included in Tank assembly
- [F] Included in Piston kit

Always use REHOBOT original spare parts