



PHS280-2400L

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	44368 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT301 Gauge	45037
6	1	O-ring	[A D]
7	1	Spring	[A D]
8	1	Ball	[A D]
9	1	Ball	[A D]
10	1	Ball	[A D]
12	1	Plug	[A D]
13	1	Packing	[A D]
14	1	Wiper	[A D]
15	1	O-ring	[A D]
16	1	Washer	[A D F]
17	1	Bushing	[D F]
18	1	O-ring	[A D F]
19	1	O-ring	[A D F]
20	1	Support ring	[A D F]
21	1	Piston	[D F]
22	1	Piston	[D F]
23	1	Housing	45590 [D]
24	1	O-ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1	Ball	[A D]
35	1	Plug	[A D]
36	1	Safety valve Cpl.	44913
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-ring	[A D]
40	1	End plate, front	[E]
41	1	O-ring	[A E]
42	1	Ball	[A E]
43	1	Screw	[E]
44	1	Oil container	[E]
45	1	Plug	[A E]
46	1	Packing	[A E]
47	1	O-ring	[A E]
48	1	End plate, rear	[E]
49	1	Yoke	44370
50	1	Packing	[A E]
51	1	Nut	[A E]

Pos.	QTY	Description	Part No.
52	1	Label, read manual	[A E]
53	1	Label, release function	[A E]
54	2	Label, REHOBOT	[A E]
		Repair kit	45591
		Handle assembly	45592
		Release valve assembly	45054
		Pump unit Cpl.	45593
		Tank assembly	45063
		Piston kit	45594

- [A] Included in Repai kit
- [B] Included in Handle assembly
- [C] Included in release valve assembly
- [D] Included in Pump unit Cpl.
- [E] Included in Tank assembly
- [F] Included in Piston kit